

LPW BILLET BREATHER

Installation

1. Determine desired breather location area on valve cover. If required, drill 1-3/16" diameter hole.
Note: Location of breathers should not be directly over rocker arms.
2. Remove breather cap from breather base and install breather base onto valve cover.
3. Tighten mounting nut to 10 ft./lbs. of torque.
Note: Do not over torque the mounting nuts or damage may occur.
4. Apply a small amount of lubricant/oil on breather base threads and o-rings.
5. Install breather cap onto base.
6. Attach vent hose to the breather and the header adapter or OEM anti-back pressure valve.
Note: LPW part no. 601 requires use of OEM style anti-back pressure valve and is recommended for full and open exhaust systems. LPW part no. 621 includes header adapter fitting and is recommended only for open exhaust systems.

Tech tip: The filter element and o-rings can be replaced with LPW part no. 681 breather rebuild kit.



Notice: LPW Racing Products, Inc. makes no warranties, implied or otherwise, of merchantability or compatibility for a particular purpose or application concerning any service performed, product manufactured and/or goods sold by LPW Racing Products, Inc. Purchaser understands, agrees and assumes all risk and liability resulting from selection, installation and/or use of services performed, products manufactured and/or goods sold. In no event shall LPW Racing Products, Inc. be responsible for incidental or consequential damages, property damage, personal injury damages or death, including, without limitation, lost profits, directly or indirectly arising out of or resulting from any service performed, products manufactured and/or goods sold by LPW Racing Products, Inc. No officer, director, employee or salesman of LPW Racing Products, Inc. or any of its vendors, dealers or distributors has any authority to make any statements contrary to what is herein above written.